



Mounting Suggestions
Harley-Davidson® Softail 200mm Wide Tire Models
2006-11 FXST
2007-11 FLSTF Fatboy
2008-11 FLSTSB Crossbones
2007-10 FXSTC Softail Custom
2010-11 FLSTFB Fatboy LO
One-Piece Seat



Baseplate Features:

Mustang Softail seats will NOT fit 1999-earlier FLSTS Heritage Springers. All seats are built on 16 gauge formed steel baseplates. A welded nose tab clips into the frame mount behind the gas tank. The baseplates have rubber supports at contact points and carpet to protect the fender.

Note: On Crossbones models, springs and frame cover must be removed before installing Mustang seat.

Removal of Stock Seat

1. Remove rear fender screw.
2. Pull seat back and up to remove from bike.
3. If passenger handstrap is present, remove it before installing Mustang seat.

Installation of Mustang One-Piece Seat

1. Engage nose tab at front of seat.
2. Align rear tab and insert stock 1/4-20 fender screw.



These steps are guidelines to help you install your new Mustang Product. If you need further assistance, please call us at 800-243-1392 or 860-582-9633, Monday through Friday 9:00 – 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under [“Support”](#).

Refers to part numbers: 75588, 76364, 76386, 76388, 76389, 76390, 76400, 76401, 76403, 76404, 76405