



Mounting Suggestions

Harley-Davidson® Sportster 1982 - 2003

Solo Seat

Tools Required:

- Phillips Screwdriver
- Allen Wrench Set
- SAE Open Open-End Wrenches

Hardware:

- 1996-2003 Models
- Black Nylon Washer (Included)

Baseplate Features:

Baseplates are made of black powder coated 16 gauge steel. Polyurethane rubber bumpers protect the motorcycle and soften vibrations.



Removal of Stock Seat

One-Piece Seat

1. Remove rear fender screw located behind the passenger seat.
2. Slide seat back and up.

Two-Piece Seat

1. Remove rear fender screw located behind the passenger seat.
2. Spread foam between solo and passenger seat. Loosen solo mounting screw.
3. Remove screw at the rear of stock solo seat.
4. Slide solo seat back and up.

Mounting of Mustang Seat

1. Engage solo nose bracket onto welded frame tab.
2. A firm downward chop to the nose of the solo will push it closer to the tank.
3. Secure the rear of the solo seat to the fender with stock fender screw to complete the installation process.

Enjoy the Comfort of your new Mustang Seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 75117, 75703, 75700, 75342, 75341, 75702, 79105, 79106, 79125, 79126, 75758, 75759