



PRODUCT DESCRIPTION

2008-UP FLH TOURING MODELS	0208-2035-SMB	0208-2035-BM	0208-2035-CH
2005-2007 FLH TOURING, 2006-UP SOFTAIL & DYNA	0208-2036-SMB	0208-2036-BM	0208-2036-CH
96-03 SPORTSTER, 02-05 VROD, 96-05 SOFTAIL & DYNA	0208-2037-SMB	0208-2037-BM	0208-2037-CH
2004-UP SPORTSTER	0208-2038-SMB	0208-2038-BM	0208-2038-CH

NOSTALGIA MASTER CYLINDER CAPS

2008-UP FLH TOURING MODELS	0208-2074-SMB	0208-2074-BM	0208-2074-CH
2005-2007 FLH TOURING, 2006-UP SOFTAIL & DYNA	0208-2073-SMB	0208-2073-BM	0208-2073-CH
96-03 SPORTSTER, 02-05 VROD, 96-05 SOFTAIL & DYNA	0208-2072-SMB	0208-2072-BM	0208-2072-CH
2004-UP SPORTSTER	0208-2075-SMB	0208-2075-BM	0208-2075-CH

- Place motorcycle on a secure lift or stand.
- Remove the factory master cylinder cap, gasket, and screws. The factory screws will be reused.
Note: On 0208-2036/2037/2072/2073 applications, remove the rubber gasket from the cap and sight glass.



- Inspect the gasket for damage. Replace if necessary. Check brake fluid level and fill to factory specifications.
- Install the RSD master cylinder cap using the stock gasket and hardware.
Note: On 0208-2036/2037/2072/2073 applications, make sure the center hole on the gasket slides completely onto the center stand-off.
Note: On 0208-2038/2075 use the factory opaque plastic plate with rubber gasket.



- Install the factory master cylinder cap screws. Refer to the HD service manual for proper torque specs.



- Install the adhesive backed RSD logo badge of your choice.



- Hit the road!