

**TACHOHALTER „IRON“
FÜR HARLEY-DAVIDSON SPORTSTER XL883N**



MONTAGEANLEITUNG:

Demontieren Sie den Lampenhalter (D) von der Oberseite der Gabelbrücke.

Bringen Sie den Halter samt Scheinwerfer mit den 5/16-Schrauben an der Unterseite der Gabelbrücke an.

Platzieren Sie dabei die Hülsen (A) zwischen Halter und Gabelbrücke.

Bauen Sie das Tachometer aus dem Originalhalter aus und in den neuen Halter (B) ein.

Setzen Sie den Halter auf die aus der Gabelbrücke herausstehenden Enden der 5/16-Schrauben und befestigen Sie ihn mit den Hutmuttern (C).



Das Thunderbike-Team wünscht viel Vergnügen



Thunderbike
Güterstrasse 5
D-46499 Hamminkeln
Telefon (0049) 2852 - 6777 -33
Telefax (0049) 2852 - 5444
info@thunderbike.de

SPEEDO BRACKET "IRON"
FOR HARLEY-DAVIDSON SPORTSTER XL883N



INSTALLATION INSTRUCTIONS:

Remove headlamp bracket (D) of upper triple tree.

Mount bracket and headlight to the downside of the triple tree.
Use the 5/16 screw and spacers (A) for it.

Remove speedometer from OEM bracket and install it to the new bracket (B).

Place the new bracket (B) on the upper side of the triple tree and mount it with the nuts (C).



The Thunderbike team wished you both safety and fun
with your new parts.
Gute Fahrt!



Thunderbike
Güterstrasse 5
D-46499 Hamminkeln
Telefon(0049)2852 - 6777 -33
Telefax(0049)2852 - 5444
info@thunderbike.de