



Harley-Davidson® Softail 200mm Wide Tire Models

Harley-Davidson® Softail Models

2006-11 FXST

2007-11 FLSTF Fatboy

2008-11 FLSTSB Crossbones

2007-10 FXSTC Softail Custom

2010-11 FLSTFB Fatboy LO

Mounting Suggestions

Harley-Davidson® Softail 200mm Wide Tire Models

2006-11 FXST

2007-11 FLSTF Fatboy

2008-11 FLSTSB Crossbones

2007-10 FXSTC Softail Custom

2010-11 FLSTFB Fatboy LO

Solo Seat

Mounting Suggestions

Harley-Davidson® Softail 200mm Wide Tire Models

2006-11 FXST

2007-11 FLSTF Fatboy

2008-11 FLSTSB Crossbones

2007-10 FXSTC Softail Custom

2010-11 FLSTFB Fatboy LO

Rear Seat



Mounting Suggestions
Harley-Davidson® Softail 200mm Wide Tire Models
2006-11 FXST
2007-11 FLSTF Fatboy
2008-11 FLSTSB Crossbones
2007-10 FXSTC Softail Custom
2010-11 FLSTFB Fatboy LO
Solo Seat



Baseplate Features:

Mustang Softail seats will NOT fit 1999-earlier FLSTS Heritage Springers.
All seats are built on 16 gauge formed steel baseplates. A welded nose tab clips into the frame mount behind the gas tank. The baseplates have rubber supports at contact points and carpet to protect the fender.

Removal of Stock Seat

1. Remove rear fender screw.
2. Pull seat back and up to remove from bike.
3. If passenger handstrap is present, remove it before installing Mustang seat.

Install Mustang Solo Seat

1. Engage nose tab at front of seat.
2. Align rear tab and insert stock 1/4-20 fender screw.



These steps are guidelines to help you install your new Mustang Product. If you need further assistance, please call us at 800-243-1392 or 860-582-9633, Monday through Friday 9:00 – 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under [“Support”](#).

Refers to part numbers: 75586, 76254, 76240, 76244, 76248, 76249, 79530, 79532, 79534, 79536, 76250, 76252

[back](#)



Mounting Suggestions
Harley-Davidson® Softail 200mm Wide Tire Models
2006-11 FXST
2007-11 FLSTF Fatboy
2008-11 FLSTSB Crossbones
2007-10 FXSTC Softail Custom
2010-11 FLSTFB Fatboy LO
Rear Seat



Baseplate Features:

Mustang Softail seats will NOT fit 1999-earlier FLSTS Heritage Springers. All seats are built on 16 gauge formed steel baseplates. The baseplates have rubber supports at contact points and carpet to protect the fender. Mustang Softail solos have two side brackets that align with the large threaded holes in the Softail frames. Harley-Davidson® rear seats do not directly fit to Mustang solos.

Mounting of Mustang Rear Seat:

1. At rear of Mustang Solo seat, remove stock 1/4-20 fender screw.
2. At rear of Mustang Solo seat, install supplied spool washer and 1/4-20 x 1" long chrome screw.
3. Align tab on front of rear seat with spool washer, insert rear fender screw and tighten.

NOTE: Mustang rear seat will not fit behind HD stock front seats.



Enjoy your new Mustang Seat!



These steps are guidelines to help you install your new Mustang Product. If you need further assistance, please call us at 800-243-1392 or 860-582-9633, Monday through Friday 9:00 – 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "[Support](#)".

Refers to part numbers: 75587, 76245, 79535, 76255, 76246, 76251, 76241, 76247, 76253, 76242, 79531, 79537, 76243, 79533

[back](#)