



Harley-Davidson® Softail Models
2000-05 Heritage Springer
2005-11 Deluxe
2006-07 Springer Classic
2007-10 Heritage Classic

Mounting Suggestions

Harley-Davidson® Softail Models
2000-05 Heritage Springer
2005-11 Deluxe
2006-07 Springer Classic
2007-10 Heritage Classic

One-Piece Seat

Mounting Suggestions

Harley-Davidson® Softail Models
2000-05 Heritage Springer
2005-11 Deluxe
2006-07 Springer Classic
2007-10 Heritage Classic

Solo Seat & Rear Seat



**Mounting Suggestions
Harley-Davidson® Softail Models
2000-05 Heritage Springer
2005-11 Deluxe
2006-07 Springer Classic
2007-10 Heritage Classic
One-Piece Seat**



Baseplate Features:

Mustang Softtail seats will NOT fit 1999-earlier FLSTS Heritage Springers. All seats are built on 16 gauge formed steel baseplates. A welded nose tab clips into the frame mount behind the gas tank. The baseplates have rubber supports at contact points and carpet to protect the fender.

Removal of Stock Seat

1. Remove rear fender screw.
2. Remove nuts at back of front seat or screws at sides of front seat, depending on bike model.
3. Remove seat(s) from bike.

Install Mustang Seat

1. Insert nose tab into frame mount behind the gas tank..
2. Insert and tighten rear fender screw..



*Enjoy the comfort of your
new Mustang seat!*

These steps are guidelines to help you install your new Mustang Product. If you need further assistance, please call us at 800-243-1392 or 860-582-9633, Monday through Friday 9:00 – 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under [“Support”](#).

Refers to part numbers: 75592, 76040, 76041, 76042, 76043, 76044, 76045, 76046, 76047, 76048, 76049

[back](#)



Mounting Suggestions
Harley-Davidson® Softail Models
2000-05 Heritage Springer
2005-11 Deluxe
2006-07 Springer Classic
2007-10 Heritage Classic
Solo Seat & Rear Seat



Baseplate Features:

Mustang Softail seats will NOT fit 1999-earlier FLSTS Heritage Springers. All seats are built on 16 gauge formed steel baseplates. The baseplates have rubber supports at contact points and carpet to protect the fender. Mustang Softail solos have two side brackets that align with the large threaded holes in the Softail frames. Harley-Davidson® rear seats do not directly fit to Mustang solos.

Removal of Stock Seat

1. Remove rear fender screw.
2. Remove nuts at back of front seat or screws at sides of front seat, depending on bike model.
3. Remove seat(s) from bike.

Install Mustang Front Seat

1. Insert nose tab into frame mount behind the gas tank.
2. Insert and tighten two nuts at back of solo seat.

To add a Mustang Rear Seat at a later time to go with your Mustang Solo Seat:

1. Align front of the Mustang rear seat with slotted nuts behind driver's seat.
2. Slide rear seat into place and secure with stock rear fender screw.

NOTE: Mustang rear seat will not fit behind HD stock front seats.



*Enjoy your new
Mustang Seat!*

These steps are guidelines to help you install your new Mustang Product. If you need further assistance, please call us at 800-243-1392 or 860-582-9633, Monday through Friday 9:00 – 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under [“Support”](#).

Refers to part numbers: 75590, 75591, 76170, 76171, 76172, 76173, 76174, 76175, 76176, 76177, 76178, 76179, 76180, 76181, 76182, 76183, 76184, 76185, 76186, 79485, 79486, 79487, 79488, 79489, 79490, 79491, 79492, 79710, 79711, 79712, 79713

[back](#)