

# Installation of CAN-Adapter(s)

## For Turn Signal Operation

Left turn signal:

1. Using supplied Posi-Tap, connect Red wire to Left Turn (Purple) wire of bike.
2. Using supplied Posi-Tap, connect Black wire to Ground (Black) wire of bike.

Right turn signal:

1. Using supplied Posi-Tap, connect Red wire to Right Turn (Brown) wire of bike.
2. Using supplied Posi-Tap, connect Black wire to Ground (Black) wire of bike.

Test operation of turn signals.

## For Taillight Operation

1. Using supplied Posi-Tap, Connect Red wire to Red Brake (Red) Wire of Bike.
2. Using Supplied Posi-Tap, Connect Black wire to Ground (Black) Wire of Bike.
3. Test Operation.

NOTE: May need to confirm functions of wiring using 12v DC circuit tester or refer to owner's manual.

