



### PRODUCT DESCRIPTION

|   |               |              |              |
|---|---------------|--------------|--------------|
| 2008-UP FLH TOURING MODELS                        | 0208-2035-SMB | 0208-2035-BM | 0208-2035-CH |
| 2005-2007 FLH TOURING, 2006-UP SOFTAIL & DYNA     | 0208-2036-SMB | 0208-2036-BM | 0208-2036-CH |
| 96-03 SPORTSTER, 02-05 VROD, 96-05 SOFTAIL & DYNA | 0208-2037-SMB | 0208-2037-BM | 0208-2037-CH |
| 2004-UP SPORTSTER                                 | 0208-2038-SMB | 0208-2038-BM | 0208-2038-CH |

### NOSTALGIA MASTER CYLINDER CAPS

|   |               |              |              |
|---|---------------|--------------|--------------|
| 2008-UP FLH TOURING MODELS                        | 0208-2074-SMB | 0208-2074-BM | 0208-2074-CH |
| 2005-2007 FLH TOURING, 2006-UP SOFTAIL & DYNA     | 0208-2073-SMB | 0208-2073-BM | 0208-2073-CH |
| 96-03 SPORTSTER, 02-05 VROD, 96-05 SOFTAIL & DYNA | 0208-2072-SMB | 0208-2072-BM | 0208-2072-CH |
| 2004-UP SPORTSTER                                 | 0208-2075-SMB | 0208-2075-BM | 0208-2075-CH |

- Place motorcycle on a secure lift or stand.
- Remove the factory master cylinder cap, gasket, and screws. The factory screws will be reused.  
**Note:** On 0208-2036/2037/2072/2073 applications, remove the rubber gasket from the cap and sight glass.



- Inspect the gasket for damage. Replace if necessary. Check brake fluid level and fill to factory specifications.
- Install the RSD master cylinder cap using the stock gasket and hardware.  
**Note:** On 0208-2036/2037/2072/2073 applications, make sure the center hole on the gasket slides completely onto the center stand-off.  
**Note:** On 0208-2038/2075 use the factory opaque plastic plate with rubber gasket.



- Install the factory master cylinder cap screws. Refer to the HD service manual for proper torque specs.



- Install the adhesive backed RSD logo badge of your choice.



- Hit the road!