



MORE POWER : LESS NOISE



Congratulations, you have purchased the finest exhaust system for your motorcycle on the market. Your Vance & Hines exhaust system is designed and crafted for maximum performance, a perfect fit, a great sound and unbeatable style. Please follow the installation instructions below and if you have any questions, please call our technical support line at (562) 926-5291.

Attention installer (if other than owner), please forward this instruction sheet to the owner of this product. These instructions contain valuable information to the end user.

TOOLS REQUIRED

- Flat blade screwdriver
- 5/16" Nutdriver
- 1/2", 9/16" & 14mm Combination wrenches
- 1/4", 3/16" & 5/16" Allen wrench
- Snapping pliers
- Ft./Lb. Torque wrench
- 3/8" Ratchet & Extensions, 1/2" Socket, 1/2", 9/16" & 5/8" deep sockets,

READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

STOCK EXHAUST SYSTEM REMOVAL

1. Remove both left and right saddlebags and set them aside.
2. Loosen the bolt from the pinch clamp on the front end of muffler(s). NOTE: On OE two into one right side only exhaust systems, there is no left side removal of mufflers required.
3. Remove the two 5/16" bolts and washers that mount the muffler(s) to the saddlebag supports. Save these for re-use.
4. Remove the stock muffler(s) and set aside. NOTE: It may be necessary to use a penetrating lubricant to loosen muffler(s) from the head pipe.
5. Locate and unplug the O2 sensor wires from the wiring harness (Grey and Black connectors located behind right side panel) and remove cable ties holding wires to frame. Feed the end of the wires through the frame so they are free from the motorcycle. NOTE: Pay attention to wire routing for re-installation.
6. Remove the right hand floor board.
7. Remove the right hand passenger floor board.
8. Loosen head pipe clamp connecting the left side muffler to the header and the mount bracket on the backside of the oil pan. Remove the crossover section of head pipe and head pipe clamp (OE dual muffler systems only).
9. Remove the mount clamp located behind the oil pan, set the 1/4"-20 x 3/4" screws aside for reuse.
10. Loosen the nut and carriage bolt holding the front head pipe to the bracket on the transmission housing.
11. Loosen the heat shield clamps on both front and rear exhaust pipes.
12. Remove the two flange mounting nuts from each head pipe, located at the cylinder head. Carefully remove the head pipes and set aside.
13. Using a 14mm wrench, carefully remove the O2 sensors from the stock head pipes and save for re-use with the new system.
14. Carefully remove the exhaust port flanges and circlips from the stock exhaust system using snapping pliers. NOTE: If circlips look bent or twisted, replace them.
15. It is strongly recommended that stock exhaust gaskets be replaced with V&H kit #22899. Carefully remove the stock exhaust gaskets, and replace them with new gaskets.

FIGURE 1



FIGURE 2



FIGURE 3




FIGURE 4




FIGURE 5



FIGURE 6




FIGURE 7





FIGURE 8



VANCE & HINES EXHAUST SYSTEM INSTALLATION

1. Install the crosspipe support bracket (stamped 564-P)(supplied) at the stock location behind the oil pan with the stock 1/4"-20 x 3/4" screws (Figure 1)
NOTE: Do not fully tighten at this time.
2. Replace the bracket on the transmission housing with new bracket (stamped 514-P) (supplied) and torque to 13-16 ft. lbs. (Figure 6).
3. Remove head pipes and heat shields from protective packaging. Place each heat shield on a non-abrasive surface such as blanket or carpet. Using a pencil, mark outside edge of each heat shield to show location of mounting clips that hose clamps will loop through (Figure 2).
4. Lay head pipes into heat shields and loosely install the #20 hose clamps (supplied) into mounting clips (Figure 2). NOTE: Screw heads should be accessible when the system is installed on motorcycle for adjustment purposes (Figure 3). Do not tighten at this time.
5. Apply a small amount of anti-seize compound to the threads of the O2 sensors and install them into the new head pipes, (Grey connector into front headpipe, Black connector into rear headpipe). NOTE: Be careful not to get anti-seize on sensor tip, it may affect sensor function.
6. Install circlips and flanges from stock system onto both new head pipes (Figure 4).
7. Using stock flange nuts, carefully install head pipes onto motorcycle. Do not tighten at this time.
8. Install the nut plates and 5/16" x 5/8" flange bolts (supplied) to attach the pipes to the bracket 514-P (Figure 5) . Do not tighten at this time.
9. Install Torca Band Clamp (supplied), with the nut facing down, on the short side expanded end of the front head pipe (D597FC) (Figure 1) Do Not tighten clamp at this time.
10. Align pipes on motorcycle so the gap between the two heat shields is parallel where they run together. Tighten the exhaust port flange nuts and the 5/16" x 5/8" flange head bolts on main bracket.
11. Referring to Figure 7 - Fasten the crossover pipe to the crossover bracket using supplied hardware. First place the crossover bracket between the arms of the header clamp. Next insert the 3/8"-16 x 1.5 flange head bolt through the header clamp, crossover bracket, heavy 3/8" washer and once again the arm of the header clamp. Lastly install a 3/8" thin flat washer and 3/8"-16 lock nut. NOTE: Do not tighten at this time.
12. Attach crossover header (D558FC) loosely to Heat shield (D567HP) and slip into end of front head pipe.
13. Tighten the stock 1/4"-20 screws securing the bracket to the oil pan, then rotate crossover head pipe (D558FC) to proper position for muffler being used. Next tighten flange head bolt and locknut securing the crosspipe clamp (A223CC) to the rear transmission bracket.
14. Install mufflers of your choice onto both head pipes and secure to saddlebag supports with the stock 5/16" bolts and lock washers. On bike equipped with OE 2 into 1 systems, Vance and Hines Left Side Mount Kit #16933 may be required to complete installation.
15. Tighten the Torca band clamp securing the crosspipe to the head pipe.
16. Route O2 sensor wires away from hot areas of the motorcycle. Use the nylon cable ties (supplied) to secure the O2 sensor wires to the frame. Plug the O2 sensor wires back into the wiring harness, grey into grey, black into black. Re-install the right side panel.
17. Install Spacer (593-P), on floor board support plate (Figure 8). Remove the left 3/8" socket cap screw only and place the spacer onto floor board support plate aligning the holes in the spacer with those on the support plate. Re-install the 3/8" socket cap screw into the original hole capturing spacer. NOTE: You may use the 3/8" stock socket cap screw to temporarily hold spacer alignment while tightening the 3/8" socket cap screw.
18. Install a 3/8" lock washer (supplied) on the 3/8"-16 x 3" socket cap screw (supplied). Using this bolt re-install the floor board with one 1" spacing washer (supplied) (Figure 8) on the forward (right) mount. NOTE: Spacing washer are located between the floor board supports and floor board mount plate. On 2010-11 CVO Models, a 3/8"-16 x1-1/2" socket cap screw (not supplied) should be used from the inside on the right mount rather than the 3/8"-16 x 3" provided bolt.
19. Re-install the right side passenger floor board.
20. Re-install the saddlebags.
21. Be sure to tighten all hardware before starting your motorcycle.
22. After installation and before starting the motorcycle, completely clean pipes and mufflers with soapy water and a clean soft cloth that will not leave residue. NOTE: Any residue, oil, or fingerprints will stain the finish when the metal heats up.

EXHAUST CARE - HELPFUL HINTS TO AVOID DISCOLORATION OF EXHAUST SYSTEM

1. When installing a new set of black pipes, make sure your hands are clean and free of oil. After installation, thoroughly clean pipes with a soft cloth and warm soapy water to remove residue before starting the motorcycle. Do not use anything abrasive to clean pipes.
2. Avoid long periods of idling as this can cause discoloration.
3. Intake leaks can cause the engine to run lean and overheat, this could lead to discoloration.
4. Make sure there are no exhaust leaks at the junction of the exhaust pipes and cylinder head. We recommend replacing gaskets if they are worn.

VANCE & HINES OPTIONAL ACCESSORIES

FUELPAK




FUEL MANAGEMENT:

Take the guess work out of fuel injection with Fuelpak Fuel Management. Contact your local dealer or call (562) 921-0071 to order. Visit fuelpakfi.com for more information. Fuelpak is intended for racing or off-highway use only, and is not legal for sale or use in California on pollution-controlled vehicles.


PLEASE NOTE: Every effort is made for Vance & Hines Exhaust Systems to provide improved cornering clearance. However, due to design and space limitations on some motorcycle models, ground and cornering clearance may not be improved and in some cases may be reduced. Be sure to follow proper installation instructions.




PACKING LIST




Nylon Cable Tie x 2




3/8"-16 x 3.0" Socket head cap screw x 1




#20
Hose Clamps x 9



Torca Band Clamp x 1





Nut plate x 2




5/16" Flange Head Bolt x 4


3/8" Lock Washer x 1



3/8"-16 x 1 1/4 Flange head Bolt x 1





Header tube clamp x 1




1" x 3/16"
Washer x 2

3/8" Flat washer x 1



593-P x 1



3/8" Lock Nut x 1

PARTS NOT SHOWN:

514-P	Mounting Bracket	x1
564-P	Mounting Bracket	x1
D597FC	Front Header Assembly	x1
D243HP	Front Heatshield	x1
D598FC	Rear Header Assembly	x1
D244HP	Rear Heatshield	x1
D558FC	Crosspipe Header Assembly	x1
D567HP	Crosspipe Heatshield	x1

WARRANTY

Vance & Hines exhaust systems are warranted against defects in material and workmanship for a period of 90 days from the date of purchase from an authorized dealer. This warranty does not cover discoloration of chrome finishes. This warranty is limited to the repair or replacement of a product proven to be defective from normal use. Vance & Hines exhaust systems are designed to fit and operate on OEM motor and chassis. This warranty does not cover any product subject to abuse, misuse, improper installation or modification.

MORE POWER : LESS NOISE

ALL PARTS SHOWN ARE ACTUAL SIZE

FUEL MANAGEMENT

GET THE MOST OUT OF YOUR RIDING EXPERIENCE...

AN AFTERMARKET EXHAUST SYSTEM IS ONLY YOUR FIRST STEP, NOW YOU NEED FUEL MANAGEMENT.

NOW YOU NEED FUELPAK.

Your fuel injected Harley-Davidson® is equipped with an ECU (electronic control unit) that's programmed to deliver fuel to the motor based on an air/fuel ratio for a stock air filter and stock exhaust system. When you install a performance exhaust system, your airflow changes, so you need a fuel management system that adjusts your air/fuel ratio to match the changes. That fuel management system is Fuelpak. Fuelpak adds and takes away fuel, allowing for a more precise range of refinement in your air/fuel ratio. Get the perfect fuel management combination with your Vance & Hines exhaust system, get Fuelpak. For more information visit the tuning center at fuelpakfi.com

NOTICE: Fuelpak is intended for racing or off-highway use only, and is not legal for sale or use in California on pollution-controlled vehicles.



MORE POWER : LESS NOISE

13861 ROSECRANS AVENUE / SANTA FE SPRINGS, CA 90670
SALES: (562) 921-5388 / TECHNICAL: (562) 926-5291 / FAX: (562) 802-0110
VANCEANDHINES.COM